

# 41 211/111 ED





# MOUNTING INTERFACE



### **PERFORMANCES** (with mineral oil of viscosity of 36 cSt at 50°C)

	viscosity of 36 cSt at 50	0)			
Maximum operating pressure:		CC	CA		
- ports P - A - B - port T	bar	28 250	30 160		
Maximum flow rate	l/min	50			
Pressure drop ∆p-Q	see	paragraph 4			
Operating limits	see	see paragraph 5			
Electrical features	see	see paragraph 7			
Electrical connections	see	see paragraph 12			
Ambient temperature range	°C	-20 / +50			
Fluid temperature range	°C	-20 / +80			
Fluid viscosity range	cSt	10 ÷ 400			
Fluid contamination degree	J J	according to ISO 4406:1999 class 20/18/15			
Recommended viscosity	cSt 25				
Masse: single solenoid valve double solenoid valve	kg	kg 1,1 1,4			


# DL3 SOLENOID OPERATED DIRECTIONAL CONTROL VALVE COMPACT VERSION

# SUBPLATE MOUNTING

ISO 4401-03 (CETOP 03)


p max 280 bar
Q max 50 l/min

# **OPERATING PRINCIPLE**



- Direct acting, subplate mounting directional control valve, with mounting surface according to ISO 4401-03 (CETOP RP 121H) standards.
- Compact design with reduced solenoid dimensions, suitable for mini-power packs and mobile and agricultural applications.
- The valve body is made with high strength iron castings provided with wide internal passages in order to minimize the flow pressure drop. Wet armature
  - solenoids with interchangeable coils are used (for further information on solenoids see paragraph 7).
  - The valve is supplied with 3 or 4 way designs and with several interchangeable spools with different porting arrangements.
  - The valve is available with DC or AC current solenoids and with several types of electrical connections to cover various installation requirements (see paragraphs 7, 12 and 13).
  - The DC valve comes with boot protected manual override which ensures a protection degree IP69K with connections type K7 and K8.

### **1 - IDENTIFICATION CODE**





# 2 - HYDRAULIC FLUIDS

Use mineral oil-based hydraulic fluids HL or HM type, according to ISO 6743-4. For these fluids, use NBR seals (code N). For fluids HFDR type (phosphate esters) use FPM seals (code V). For the use of other fluid types such as HFA, HFB, HFC, please consult our technical department.

Using fluids at temperatures higher than 80 °C causes a faster degradation of the fluid and of the seals characteristics. The fluid must be preserved in its physical and chemical characteristics.

# 3 - SPOOL TYPE






# 4 - PRESSURE DROPS $\Delta p$ -Q (obtained with viscosity of 36 cSt at 50 °C)

		FLOW DIRECTIONS				
SPOOL	P→A	P→B	A→T	B→T	P→T	
		CURVE	S ON G	RAPHS		
S1	1	1	1	1	-	
S2	1	1	2	2	3	
S3	3	3	2	2	-	
S4	4	4	4	4	5	
RK	1	1	1	1	-	
ТА	3	3	3	3	-	

#### **5 - OPERATING LIMITS**

The curves define the flow rate operating fields according to the valve pressure of the different versions. The values indicated in the graphs are relevant to the standard solenoid valve. The operating limits can be considerably reduced if a 4-way valve is used as 3-way valve with port A or B plugged or without flow.

The values have been obtained according to ISO 6403 norm with solenoids at rated temperature and supplied with voltage equal to 90% of the nominal voltage. The value have been obtained with mineral oil, viscosity 36 cSt, temperature 50 °C and filtration according to ISO 4406:1999 class 18/16/13.



SPOOL	CURVE
S1, RK, TA	1
S2	2
S3	3
S4	4

ENERGIZED VALVE

SPOOL	CURVE
S1, RK, TA	1
S2	2
S3	3
S4	4

# 6 - SWITCHING TIMES

The values indicated are obtained with spool S1, according to ISO 6403 standard, with mineral oil viscosity 36 cSt at 50°C.

SUPPLY	TIMES (±10%) [ms]				
SUPPLI	ENERGIZING	DE-ENERGIZING			
DC	25 ÷ 75	15 ÷ 25			
AC	10 ÷ 25	15 ÷ 30			

# 7 - ELECTRICAL FEATURES

#### 7.1 Solenoids

These are essentially made up of two parts: tube and coil. The tube is threaded into the valve body and includes the armature that moves immersed in oil, without wear. The inner part, in contact with the oil in the return line, ensures heat dissipation.

The coil is fastened to the tube by a threaded ring, and can be rotated +/-  $90^{\circ}$ , to suit the available space.

The interchangeability of coils of different voltages is allowed within the same type of supply current, alternating or direct.

Protection from	n atmospheri	c agents CE	I EN 60529
	in admoophorn	o agointo o E	

Plug-in type	IP 65	IP 67	IP 69 K
K1 DIN 43650	x (*)		
K2 AMP JUNIOR	х	x (*)	
K4 outgoing cable	x	х	
K7 DEUTSCH DT04 male	х	х	x (*)
K8 AMP SUPER SEAL	x	х	x (*)

(\*) The protection degree is guaranteed only with the connector correctly connected and installed

**NOTE**: In order to further reduce the emissions, with DC supply, use of type H connectors is recommended. These prevent voltage peaks on opening of the coil supply electrical circuit (see cat. 49 000).

SUPPLY VOLTAGE FLUCTUATION	± 10% Vnom
MAX SWITCH ON FREQUENCY	10.000 ins/hr
DUTY CYCLE	100%
ELECTROMAGNETIC COMPATIBILITY (EMC)	In compliance with 2004/108/CE
LOW VOLTAGE	In compliance with 2006/95 CE
CLASS OF PROTECTION : Coil insulation (VDE 0580) Impregnation:	class H class H

#### 7.2 DC valve - Current and power consumption

In direct current energizing, current consumption stays at fairly constant values, essentially determined by Ohm's law: V = R x I

"R" coil must be used when the valve is fed with AC power supply subsequently rectified by means of rectifier bridge, externally or incorporated in the "D" type connector (see cat. 49 000).

The table shows current and power consumption values for CC and RC coil types.


	Nominal voltage	Resistance at 20°C	Current consumption	Power consumption (±5%)				Coil code		
	[V]	[Ω] (±1%)	[A] (±5%)	[W] [VA]		K1	K2	K4	K7	K8
D12	12	5,4	2,2	26,5		1902740	1902750	1902770	1902980	1903020
D24	24	20,7	1,16	27,8		1902741	1902751	1902771	1902981	1903021
D28	28	27,5	1,02	28,5		1902744				
D48	48	82	0,58	28		1902745				
R110	110	363	0,25		27,2	1902742				
R230	230	1640	0,11		26,4	1902743				

## 7.3 AC valve - Current and power consumption


In alternating current energizing, an initial phase (maximum movement) is seen, during which the solenoid consumes elevated value currents (inrush current); the current values diminish during the plunger stroke until it reaches the minimum values (holding current) when the plunger reaches the stroke end. The table shows the values of absorption at the inrush and at holding.

	Nominal voltage [V]	Freq. [Hz]	Resistance at 20°C [Ω] (±5%)	Current consumption at inrush [A] (±10%)	Current consumption at holding [A] (±10%)	Power consumption at inrush (±10%) [VA]	Power consumption at holding (±10%) [VA]	Coil code K1
A24	24		2,7	4,5	1,47	109,2	35,3	1903190
A48	48	50	13,7	2,3	0,79	110,9	37,9	1903191
A110	110	50	73,4	1,0	0,31	107,8	34,1	1903192
A230	230		320	0,5	0,16	112,7	36,8	1903193

# 8 - DL3 DC OVERALL AND MOUNTING DIMENSIONS



# 9 - DL3 AC OVERALL AND MOUNTING DIMENSIONS




# **10 - INSTALLATION**

Configurations with centering and return springs can be mounted in any position; type RK valves - without springs and with mechanical detent - must be mounted with the longitudinal axis horizontal.

Valve fitting takes place by means of screws or tie rods, fixing the valve on a lapped surface, with values of planarity and smoothness that are equal to or better than those indicated in the drawing.

If the minimum values of planarity or smoothness are not met, fluid leakages between valve and mounting surface can easily occur.



## **11 - OPTIONAL MANUAL OVERRIDES**

#### 11.1 - Boot protected manual override

On the DC version the boot override is integrated in the coil locking ring, as standard.

On the AC version, however, the boot override can be ordered by entering the code **CM** in the identification code at par. 1, or is available as option to be ordered separately: code **3401210001**.

#### 11.2 - Knob manual override

Available only for DC version


When the set screw is screwed and its point is aligned with the edge of the knob, tighten the knob till it touches the spool: in this position the override is not engaged and the valve is de-energized. After adjusting the override, tighten the set screw in order to avoid the knob loosing.

#### Spanner: 2.5 mm


The knob override can be ordered by entering the code **CK** in the identification code at par. 1, or is available as option to be ordered separately: code **3401210002**.

# **12 - ELECTRIC CONNECTIONS**


connection for DIN 43650 connector type code **K1** (standard)





outgoing cable connections code **K4** 





connection for AMP SUPER SEAL (two contacts) connector type code **K8** 













connection for DEUTSCH DT04-2P for male connector type DEUTSCH DT06-2S code **K7** 




# **13 - ELECTRIC CONNECTORS**

The solenoid operated valves are delivered without connector. For coils with standard electrical connections K1 type (DIN 43650) the connectors can be ordered separately. For the identification of the connector type to be ordered please see cat. 49 000. For K2, K7 and K8 connection type the relative connectors are not available.

# 14 - SPARE PARTS FOR DC SOLENOID VALVE



# **15 - SPARE PARTS FOR AC SOLENOID VALVE**



# **16 - FASTENING BOLTS AND SEALING RINGS**

Single valve fastening: 4 SHC screws M5x30 - ISO 4762

Tightening torque: 5 Nm

Threads of mounting holes: M5x10

Sealing rings: N. 4 OR type 2037 (9.25x1.78) - 90 Shore



DUPLOMATIC OLEODINAMICA S.p.A. 20015 PARABIAGO (MI) • Via M. Re Depaolini 24 Tel. +39 0331.895.111 Fax +39 0331.895.339 www.duplomatic.com • e-mail: sales.exp@duplomatic.com **17 - SUBPLATES** (See catalogue 51 000)

Type PMMD-AI3G with rear ports
Type PMMD-AL3G with side ports
P, T, A, B port threading: 3/8" BSP